



Comments: Fasteners must embed into nailer 25mm (1") min.
Membrane must be fully adhered from roof edge to first row of membrane fasteners.



**Roof Edge
(Edge System)
Roofing System Detail**

Scale: Not to scale
Date: August, 2016
Detail No.: P-S-201